# Install and run Raspbian from a USB Flash Drive

• 20 MAY, 2013

#### SEE ALSO: http://www.raspberrypi.org/forums/viewtopic.php?f=29&t=44177 which is a better (?) instruction on this subject

In this tutorial, I'm going to talk you through running Raspbian from a USB connected drive instead of from an SD card. Running from a USB connected Flash or Hard Drive has many advantages, the biggest being speed and reliability.

SD Cards have a limited read/write cycle, and when hosting a site with a MySQL database from a SD card, it won't take long before you start getting corruptions and failures. USB Flash drives provide a cheap and reliable alternative. I've tested several USB Flash drives, and found Sandisk and Corsair to be the best for speed and reliability. This site is run off a 16GB Corsair Voyager 3 USB Flash drive.

#### Assumptions before we begin

I'm going to assume that you know your way around Terminal, and are using a Mac to perform these steps. You will still need an SD card to store the boot instructions to tell the Raspberry Pi to launch the OS from the USB; the Raspberry Pi's can't (yet) boot directly from a USB storage device.

# Step 1 – Download Raspbian from Raspberry Pi

You will need the standard Raspbian OS image, you can download this from the official Raspberry Pi website. Once you've downloaded it, unzip it. It's around 400mb in size, so should only take a couple of minutes over a broadband connection.

# Step 2 – Install the Raspbian OS to your USB Flash drive

Plug in your USB stick and launch Terminal. The first thing we're going to do is get the device identifier for your USB Flash drive. To do this run the following command:

diskutil list

The list of attached disks will show up with their identifiers. Important – make a note of the correct identifier, you can do some serious damage by choosing the wrong one!

MacBook-A	ir:~ sjwright\$ diskutil	list		
/dev/disk	0			
#:	TYPE	NAME	SIZE	IDENTIFIER
0:	GUID_partition_scheme		*500.3 GB	diskØ
1:	EFI		209.7 MB	disk0s1
2:	Apple_CoreStorage		399.4 GB	disk0s2
3:	Apple_Boot	Recovery HD	650.0 MB	disk0s3
4:	Microsoft Basic Data	BOOTCAMP	100.0 GB	disk0s4
/dev/disk	1			
#:	TYPE	NAME	SIZE	IDENTIFIER
0:	Apple_HFS	Macintosh HD	*399.1 GB	disk1
/dev/disk	2			
#:	TYPE	NAME	SIZE	IDENTIFIER
0:	FDisk_partition_scheme		*4.0 GB	disk2
1:	DOS_FAT_32	SANDISK	4.0 GB	disk2s1
MacBook-A	ir:~ sjwright\$			

In the screen shot above, I can see that /dev/disk2 is the correct identifier for my Sandisk USB Flash Drive. Yours may be different so change to suit your configuration. Next we're going to unmount the USB Flash Drive. To do this enter the following command:

diskutil unmountDisk /dev/disk2

Yet again, be really careful to change disk2 to whatever your computer identifies the USB Flash Drive as. You will get a message saying

"Unmount of all volumes on disk2 was successful".

Now we can begin the copy. For ease, I've changed the directory in Terminal to where the Raspbian image is located, which in this case is my downloads folder. If you've downloaded and unzipped the disk image to your downloads folder, running this command should take you there:

cd ~/Downloads/

Now run this command to begin the copy:

sudo dd bs=1m if=2013-02-09-wheezy-raspbian.img of=/dev/disk2

As with before, make sure you change disk2 to whatever your computer identifies as being the USB Flash Drive, and change 2013-02-09-wheezy-raspbian.img to whatever your image file is called. The blocks will now begin moving to your USB Flash Drive from the Raspbian OS image. This takes anything from 5 to 20 mins depending on the speed of your USB Flash Drive. Go stick the kettle on and have a brew!



Eventually, you will see something similar to the above, and it probably took a while too. The next step is to configure your SD Card to give the correct boot instruction to start the OS from the USB Flash Drive

#### Step 3 – Configure your SD card

Using Disk Utility, format your SD Card using FAT32. It's dead easy, choose your SD Card from the devices listed on the right, then click on 'Erase', choose FAT32 in the Formats list and click on 'Erase'.

000	APPLE SD Card Reader Media	144.42.13
Verify Info Burn Mount	Eject Enable Journaling New Image Convert Resize Image	Log
Macintosh HD Macintosh HD BOOTCAMP 4 GB SanDisk Cruzer Media Untitled 1 disk2s2 1:98 GB APPLE SD Card	First Aid   Erase   Partition   RAID   Restore     To erase all data on a disk or volume:   1   Select the disk or volume in the list on the left.     2   Specify a format and name.   3   If you want to prevent the recovery of the disk's erased data, click Security Options     4   Click Erase.     To prevent the recovery of previously deleted files without erasing the volume, see volume in the list on the left, and click Erase Free Space.     Format: MS-DOS (FAT)     Name:   UNTITLED     Erase Free Space	ect a
Disk Description : / Connection Bus : U Connection Type : I USB Serial Number : 0	APPLE SD Card Reader Media Total Capacity: 1.98 GB (1,977,614,336 Bytes)   JSB Write Status: Read/Write   Internal S.M.A.R.T. Status: Not Supported   100000000310 Partition Map Scheme : Master Boot Record	



Once you've done this, you'll notice on your Desktop, there are two mounted volumes; one is your USB Flash Drive, the other is your SD Card.

Open up the USB Flash Drive volume and copy all the files from that onto your SD card. This copies the all-important files and instructions to tell your Raspberry Pi to boot from the USB Flash Drive. We're almost done at this point, only one more step to go.

# Step 4 – Change the boot path on your SD card

Once you've completed step 3, you need to change the default boot path to tell the Raspberry Pi to boot from your USB drive. Open a new Finder window and go to your SD card. Open up the file called cmdline.txt in TextEdit or similar and amend the line which reads:

root=/dev/mmcblk0p2

To this:

root=/dev/sda2

This will instruct your Raspberry Pi to boot from the USB Flash Drive instead of from the SD card. Save the cmdline.txt file and close the Finder window. We're almost done!

# Step 4 – Boot from your USB Flash Drive on your Raspberry Pi

Now unmount both your USB Flash Drive and your SD card and pop them both into your Raspberry Pi and switch it on. If all goes well, it should boot from your USB Flash Drive which you'll find substantially quicker than your SD Card.

# Step 5 – Expand the Raspbian partition on your USB Flash drive to fill it

Finally, we're just going to do a little housekeeping to utilise all the available space on your USB Flash drive as the method using raspi-config doesn't work on USB Flash drives. This isn't essential, but if you have the extra space on a USB Flash Drive, why not use it all?

From your Raspberry Pi, type the following command to start FDisk:

sudo fdisk /dev/sda

Then press p and enter to see the partitions. There should only be 2. What we're going to do now is delete the Linux partition, but before we do this, we make a note of the start position for the linux partition sda2. Press d and then when prompted type 2 and then hit enter. This will delete the partition.

Now we're going to create a new partition, and make it large enough for the OS to occupy the full space available on the USB Flash Drive. To do this type n to create a new partition, when prompted to give the partition type, press p for primary. Then it will as for a partition number, press 2 and hit enter.

You will be asked for a first sector, set this as the start of partition 2 as noted earlier. In my case this as 12280 but this is likely to be different for you.

After this it will ask for an end position, hit enter to use the default which is end of disk. Now type w to commit the changes. You will see a message about the Kernel using some table yaddah yaddah, just ignore this. Type the following to reboot:

sudo reboot

Once your Raspberry Pi has rebooted, we need to resize the partition. To do this type the following command:

sudo resize2fs /dev/sda2

Be patient, this will take some time. Once it's done reboot again. Then type:

df -h

This will show the partitions and the space, you'll see the full USB Flash Disk has all the space available now. That's it, all done!

Ste Wright