

- A single supply from a powered hub. Most hubs seem to deliver more than the specified current but there's no guarantee. Check the power supply rating. It must be enough to supply everything that's connected to the hub.
- A charging USB port. It should be able to kick more than 500mA, they work better on the board.
- A battery. A USB can draw as much as 500mA, but that's not the case with a battery. It's not a power supply for the board, it's a power source. It's not a power supply for the board, it's a power source. It's not a power supply for the board, it's a power source.

Summary

- If you are having unstable operation the first thing to do is check your power supply.
- Get a good quality regulated power supply that is rated to provide 5V and at least 1A (1000mA).
- Use a good quality USB cable. Cables are notorious for giving trouble so be prepared to swap for another one.
- Not all power supplies will deliver what they claim.

Capacitor C6

Behind the microUSB power connector on the MicroB is a metallic grey component called a capacitor, marked as C6. This capacitor helps stabilize the DC power on the board, but for some it has also become a pain for their thumb when removing the USB power lead. Unfortunately, this can result in the capacitor breaking off. It has been stated in the forums that the type of capacitor used for C6 will be changed on later RP1 models for one with slanted leads. If you do break off your C6 capacitor, it's highly likely that your RP1 will still work properly, unless you have a particularly unstable power supply, but the general advice is to not use C6 as a leverage point when removing the power connector and also take care when storing or transporting your RP1 if it's not fitted in a case - try not to stress the board where C6 could be knocked by other items - for example for a laptop carry case or an amongst some books.



Capacitor C6 (top)

It's unlikely that replacing a broken off C6 capacitor will be covered under warranty, but fortunately they are easy to replace if you have average soldering skills. (<http://www.raspberrypi.org/archives/1494>), but remember that reworking your RP1 will void its warranty too. C6 is a surface mount electrolytic capacitor with a capacitance of 220 microfarad (µF) and a voltage rating of 16 volt (V). The capacitor is polarised and so must be fitted the right way round - notice the black marking on one side in the picture above. A replacement capacitor can be purchased from numerous sources - for example:

Farnell (<http://uk.farnell.com/2ap/water/3569660.jsp>)

Rs Components (<http://www.rs-online.com/web3/Products/capacitors/Aluminum?sort-by=desc&sort-order=desc&filterApplied-dimensions=429488456,%5C24294884170,%5C24294472278,429488414&maxAffinitySelectorBlock=4294955811>)

If you prefer to make your own PSU - see [Power Supply construction - How to](#)

References

1. <http://www.raspberrypi.org/blog>
2. [Forum: Hub about removal of C6. Why was this change made?](http://www.raspberrypi.org/forum/features-and-requests/hub/about-removal-of-c6-why-was-this-change-made/) (<http://www.raspberrypi.org/forum/features-and-requests/hub/about-removal-of-c6-why-was-this-change-made/>)
3. [Forum: Hub about removal of C6. Why was this change made?](http://www.raspberrypi.org/forum/features-and-requests/hub/about-removal-of-c6-why-was-this-change-made/) (<http://www.raspberrypi.org/forum/features-and-requests/hub/about-removal-of-c6-why-was-this-change-made/>)
4. [Forum: Hub about removal of C6. Why was this change made?](http://www.raspberrypi.org/forum/features-and-requests/hub/about-removal-of-c6-why-was-this-change-made/) (<http://www.raspberrypi.org/forum/features-and-requests/hub/about-removal-of-c6-why-was-this-change-made/>)
5. [Forum: Hub about removal of C6. Why was this change made?](http://www.raspberrypi.org/forum/features-and-requests/hub/about-removal-of-c6-why-was-this-change-made/) (<http://www.raspberrypi.org/forum/features-and-requests/hub/about-removal-of-c6-why-was-this-change-made/>)
6. [Forum: Hub about removal of C6. Why was this change made?](http://www.raspberrypi.org/forum/features-and-requests/hub/about-removal-of-c6-why-was-this-change-made/) (<http://www.raspberrypi.org/forum/features-and-requests/hub/about-removal-of-c6-why-was-this-change-made/>)
7. [Forum: Hub about removal of C6. Why was this change made?](http://www.raspberrypi.org/forum/features-and-requests/hub/about-removal-of-c6-why-was-this-change-made/) (<http://www.raspberrypi.org/forum/features-and-requests/hub/about-removal-of-c6-why-was-this-change-made/>)
8. [Forum: Hub about removal of C6. Why was this change made?](http://www.raspberrypi.org/forum/features-and-requests/hub/about-removal-of-c6-why-was-this-change-made/) (<http://www.raspberrypi.org/forum/features-and-requests/hub/about-removal-of-c6-why-was-this-change-made/>)
9. <http://www.raspberrypi.org/archives/244>
10. http://www.raspberrypi.org/?page_id=42&entryidforaction=viewlog&i=285.0

Script error

Redundant from: [http://wiki.osrfoundation.org/wiki/USB_Power_Supply_Construction](#)

- This page was last modified on 3 May 2014, at 17:37.
- This page has been accessed 117,120 times.
- Content is available under a [Creative Commons Attribution-ShareAlike 3.0 Unported License](#) unless otherwise noted.